



- Ⓐ OEM Plug. H4/9004/9007
- Ⓑ Connect relay kit to OEM plug on vehicle
- Ⓒ Connect small white plug for High/Low function
- Ⓓ Connect power plug from relay kit to ballast
- Ⓔ Connect the RED wire to positive (+) terminal on battery
Connect the Black wire to negative (-) terminal on battery
- Ⓕ Power lead for LED light. Connect to park light or DRL circuit.



FUTURE VISION TECH

p | **888-LED-HID-1**

e | **sales@futurevisionled.com**

w | **www.FutureVisionLED.com**